

把手，舌片兼容表

●：可以安装 ※○：推荐在标记有※的舌片安装时使用另外的方孔垫圈，以便更加稳定

技术参数

把手	舌片										
	L-20	L-20A t=2	L-20A t=3	L-20B t=2	L-20B t=3	L-20A-SUS	L-21	L-21B 10.5八角穴	L-21B 8.2八角穴	L-24	L-24A t=1.6
(页)	528	529	529	528	528	529	527	527	527	530	531
PCH-19-1								●			
PCH-19-2/PCH-19A-2	●	●	●	●	●	●	●		●	●	●
PCH-19-SUS-1								●			
PCH-19-SUS-2	●	●	●	●	●	●	●		●	●	●
PCH-60A-SUS-1	●	●	●	●	●	●	●		●	●	●
PCH-60A-SUS-2	●	●	●	●	●	●	●		●	●	※○
PCH-119-1								●			
PCH-119-2	●	●	●	●	●	●	●		●	●	●
可拆卸把手											
PH-3-1	●	●	●	●	●	●	●		●	●	※○
PH-3-2	●	●	●	●	●	●	●		●	●	※○
PH-6-2	●	●	●	●	●	●	●		●	●	●
平面把手											
PH-13A	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-16A-1	●	●	●	●	●	●	●		●	●	※○
圆形平面把手											
PH-20	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-22S	●	●	●	●	●	●	●		●	●	●
PH-30-3	●	●	●	●	●	●	●		●	●	※○
突面把手											
PH-30-4	●	●	●	●	●	●	●		●	●	※○
PH-33	●	●	●	●	●	●	●		●		●
PH-42/PH-42K	※○	※○	●	※○	●	※○	●		●	※○	※○
摆动把手											
PH-42CY	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-42-SUS/PH-42K-SUS	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-52	※○	※○	●	※○	●	※○	●		●	※○	※○
搭扣把手											
PH-52-SUS	●	●	●	●	●	●	●		●	●	●
PH-53	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-53A	●	●	●	●	●	●	●		●	●	●
一体式把手											
PH-53-SUS	●	●	●	●	●	●	●		●	●	●
PH-54	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-55N	●	●	●	●	●	●	●		●	●	※○
密闭把手											
PH-56-SUS	●	●	●	●	●	●	●		●	●	※○
PH-57-SUS	●	●	●	●	●	●	●		●	●	※○
PH-71K/PH-71	●	●	●	●	●	●	●		●	●	※○
集装箱把手											
PH-89-1	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-89-2/PH-89A-2	●	●	●	●	●	●	●		●	●	●
PH-89-3/PH-89A-3	●	●	●	●	●	●	●		●	●	●
其他把手											
PH-89-SUS-2	●	●	●	●	●	●	●		●	●	●
PH-89-SUS-3	●	●	●	●	●	●	●		●	●	●
PH-89D-1	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-89L-1	※○	※○	●	※○	●	※○	●		●	※○	※○
PH-271K/PH-271	●	●	●	●	●	●	●		●	●	※○
L-17	※○	※○	●	※○	●	※○	●		●	※○	※○
L-177	●	●	●	●	●	●	●		●	●	※○
L-235	●	●	●	●	●	●	●		●	●	※○
L-237	NEW	●	●	●	●	●	●		●	●	●
L-345	●	●	●	●	●	●	●		●	●	※○

把手 (页)	舌片										
	L-24A t=2.3	L-24A-SUS	L-27-2	L-27-3	L-28-1	L-28-2	L-29A	L-29B	L-124A-SUS	L-189-1	L-189-2
PCH-19-1			●					●		●	
PCH-19-2/PCH-19A-2	●	●		●	●	●	●		●		●
PCH-19-SUS-1			●					●		●	
PCH-19-SUS-2	●	※○		●	●	●	●		●		●
PCH-60A-SUS-1	●	●		●	●	●	●		●		
PCH-60A-SUS-2	●	※○		●	●	●	●		●		
PCH-119-1			●					●		●	
PCH-119-2	●	●		●	●	●	●		●		●
PH-3-1	●	※○		●	●	●	●		●		
PH-3-2	●	※○		●	●	●	●		●		
PH-6-2	●	※○		●	●	●	●		●		
PH-13A	※○	※○		●	※○	※○	※○		※○		
PH-16A-1	●	※○		●	●	●	●		●		
PH-20	※○	※○		●	※○	※○	※○		※○		
PH-22S	●	●		●	●	●	●		●		
PH-30-3	●	※○		●	●	●	●		●		
PH-30-4	●	※○		●	●	●	●		●		
PH-33	●	●		●	●	●	●		●		
PH-42/PH-42K	●	※○		●	●	●	※○		※○		
PH-42CY	●	※○		●	●	●	※○		※○		
PH-42-SUS/PH-42K-SUS	●	※○		●	●	●	※○		※○		
PH-52	※○	※○		●	●	●	※○		※○		
PH-52-SUS	●	●		●	●	●	●		●		
PH-53	※○	※○		●	●	●	※○		※○		
PH-53A	●	●		●	●	●	●		●		
PH-53-SUS	●	●		●	●	●	●		●		
PH-54	※○	※○		●	●	●	※○		※○		
PH-55N	●	※○		●	●	●	●		●		
PH-56-SUS	●	※○		●	●	●	●		●		
PH-57-SUS	●	※○		●	●	●	●		●		
PH-71K/PH-71	●	※○		●	●	●	●				
PH-89-1	※○	※○		●	※○	※○	※○		※○		
PH-89-2/PH-89A-2	●	●		●	●	●	●		●		
PH-89-3/PH-89A-3	●	●		●	●	●	●		●		
PH-89-SUS-2	●	●		●	●	●	●		●		
PH-89-SUS-3	●	●		●	●	●	●		●		
PH-89D-1	※○	※○		●	※○	※○	※○		※○		
PH-89L-1	※○	※○		●	※○	※○	※○		※○		
PH-271K/PH-271	●	※○		●	●	●	●				
L-17	●	※○		●	●	●					
L-177	●	※○		●	●	●					
L-235	●	※○		●	●	●					
L-237	NEW	●		●	●	●					
L-345	●	※○		●	●	●					

旋转把手

可拆卸
把手

平面把手

圆形平面
把手

突面把手

摆动把手

搭扣把手

一体式
把手

密闭把手

集装箱
把手

其他把手